ADDENDUM

16-Minute Digital Recorder
63-1109

After removing the battery insulation strip, your recorder takes about 45 seconds to initialize. The Initialize icon appears when initialization is complete. Wait 10 seconds. The Ready icon appears, indicating your recorder is ready for use.

Initialize icon

Ready icon

© 2000 RadioShack Corporation. All Rights Reserved. RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

RadioShack Corporation
Fort Worth, Texas 76012

10A00
Printed in China